

PARTS MANUAL

Model

**RGX7500 & RGX7500E
GENERATORS**

PUB-EP
Rev. 03/12



SUBARU
Industrial Power Products

Robin America, Inc.


905 Telser Road • Lake Zurich, IL 60047 • Phone: 847-540-7300 • Fax: 847-438-5012
e-mail: sales@subarupower.com • www.subarupower.com

© Copyright 2012 Robin America, Inc.

GROUP INDEX

Group Name	Page
CRANKCASE GROUP	4
CRANKSHAFT GROUP	8
INTAKE and EXHAUST GROUP.....	10
GOVERNOR GROUP	14
COOLING and STARTING GROUP.....	16
FUEL, LUBRICATION GROUP	18
ELECTRIC.....	22

FIG. 1 CRANKCASE GROUP



960—GASKET SET

FIG. 1 CRANKCASE GROUP

FIG. 2 CRANKSHAFT GROUP




FIG. 2 CRANKSHAFT GROUP

FIG. 3 INTAKE and EXHAUST GROUP




FIG. 3 INTAKE and EXHAUST GROUP

Ref.	Part Number	Description	Qty	Remarks	Model
12	20B-31602-10	CAMSHAFT AY	1		
23	20B-35101-21	PIN(CAM SHAFT)CP	1		
27	024-00700-21	O-RING	1		
34	005-19041-00	SPRING PIN	1	4.4DX10LX0.8T	
35	277-36401-03	RELEASE LEVER	1		
37	20B-36501-03	CLIP	1		
38	20B-38701-03	RETURN SPRING	1		
48	031-80500-20	ROLL PIN	1		
60	246-33611-03	VALVE SPRING	2	22.2DX2.9DX37L N=6.5	
70	246-33711-13	SPRING RETAINER	2	7.6DX26DX8T	
80	20B-33401-H3	INTAKE VALVE	1		
90	20B-33501-H3	EXHAUST VALVE	1		
95	246-35501-03	COLLET-VALVE	4		
150	20B-35601-H1	TIMING CHAIN CP	1		
160	277-36911-03	TENTIONER	1		
163	277-37101-03	SPRING(TENTIONER)	1	10DX1.8DX14L N=4.5	
166	277-36902-03	PIN(TENTIONER)	1	6DX13DX34L	
170	277-36913-13	CHAIN GUIDE	1		
200	20B-35001-01	PIN(ROCKER)CP	1		
202	003-13060-00	CLIP	1	6DX12DX0.8T	
220	20B-36101-00	ROCKER ARM(IN) AY	1		
225	20B-36102-10	ROCKER ARM(EX) AY	1		
230	014-90500-20	ADJUST SCREW	1	M5X0.5X23L	
231	014-90500-20	ADJUST SCREW	1	M5X0.5X23L	
240	017-00500-30	NUT	1	M5X0.5X4.1H	
241	017-00500-30	NUT	1	M5X0.5X4.1H	
290	011-00600-10	FLANGE BOLT	1	M6X1.0X14DX8L	
310	36D-11001-11	MUFFLER CP	1		
315	267-37602-01	SPARK ARRESTER CP	1		
317	015-00400-60	TAPPING SCREW	1	M4X6L	
330	31H-15002-03	MUFFLER BRACKET	1		
340	20B-35201-13	GASKET(MUFFLER)	1		
341	270-35201-01	GASKET CP (MUFFLER)	2	T=0.4 30D 8.5DX52P	
350	002-38080-00	FLANGE NUT	2	M8X1.25X17DX7.5H	
351	002-18080-00	NUT	2	M8X1.25X6.5H	
353	002-38080-00	FLANGE NUT	4	M8X1.25X17DX7.5H	
356	003-20080-00	SPRING WASHER	2	8.2DX15.4DX2T	
358	020-30800-10	SPRING WASHER	2	8.2DX15.4DX2T	
365	010-30800-70	BOLT	2	M8X1.25X20L	
405	20B-34001-01	EXHAUST PIPE CP	1		
406	35G-14001-01	EXHAUST PIPE CP	1		
415	010-50802-90	STUD	2	M8X1.25X30L	
538	20B-35903-13	GASKET 3	1		
540	20B-32901-J1	INSULATOR CP	1		
550	20B-35902-H3	GASKET 2	1		
560	20B-35901-H3	GASKET 1	1		

FIG. 3 INTAKE and EXHAUST GROUP




FIG. 3 INTAKE and EXHAUST GROUP

FIG. 3 INTAKE and EXHAUST GROUP





FIG. 3 INTAKE and EXHAUST GROUP

FIG. 4 GOVERNOR GROUP




FIG. 4 GOVERNOR GROUP

FIG. 5 COOLING and STARTING GROUP




FIG. 5 COOLING and STARTING GROUP

FIG. 5 COOLING and STARTING GROUP




FIG. 5 COOLING and STARTING GROUP

FIG. 6 FUEL LUBRICANT GROUP




FIG. 6 FUEL LUBRICANT GROUP

FIG. 6 FUEL LUBRICANT GROUP




FIG. 6 FUEL LUBRICANT GROUP

FIG. 7 ELECTRIC GROUP




FIG. 7 ELECTRIC GROUP

FIG. 7 ELECTRIC GROUP




FIG. 7 ELECTRIC GROUP

FIG. 7 ELECTRIC GROUP




FIG. 7 ELECTRIC GROUP

FIG. 7 ELECTRIC GROUP




FIG. 7 ELECTRIC GROUP

FIG. 7 ELECTRIC GROUP




FIG. 7 ELECTRIC GROUP

FIG. 9 ACCESSORY GROUP




FIG. 9 ACCESSORY GROUP

FIG. 10 SHIP LOOSE

(Illustrations are excluded.)

(FIG 1000は単独発送部品につき、
イラストは省略します。)

FIG. 10 **SHIP LOOSE**

FIG. 22 GROUP




FIG. 22 GROUP

FIG. 23 GROUP





FIG. 23 GROUP

FIG. 24 GROUP




FIG. 24 GROUP

Ref.	Part Number	Description	Qty	Remarks	Model
100	35H-70103-00	CONTROL BOX AY	1		
110	35G-71101-02	CONTROL BOX UN	1		
303	31H-74001-01	AVR UN	1		
310	392-49986-08	SCREW	4	M4X6L	
360	353-45815-08	DIODE STACK AY	1		
362	35G-72015-03	SCREW	1		
363	002-17040-00	NUT	1		
370	KU3-11015-01	IDLE C/U CP (150V)	1		
372	001-13062-00	BOLT AND WASHER AY	2		
373	002-17060-00	NUT	2	M6X1.0X5H	
480	35C-72014-03	FLANGE BOLT	5		
490	31H-75009-03	GROMMET	1		
500	35H-70203-00	CONTROL PANEL AY	1		Recoil Only
500	35H-70204-00	CONTROL PANEL AY	1		Electric Start Only
505	35G-71001-01	CONTROL PANEL	1		Recoil Only
505	35G-71002-01	CONTROL PANEL	1		Electric Start Only
520	35A-72002-03	ROCKER SWITCH	1		Recoil Only
520	066-00003-30	SWITCH	1		Electric Start Only
520-1	066-00099-80	KEY,SWITCH	2	MARK 103	Electric Start Only
523	344-45615-08	AUTO IDLE SWITCH	1		
526	355-45613-11	SWITCH AY(9P)	1		
530	35B-72003-03	AC RECEPTACLE	1	125V/30A	
531	35C-72005-03	AC RECEPTACLE	1		
532	388-85003-01	AC RECEPTACLE	2	125V-20A	
535	31C-79001-03	SCREW & WASHER AY	4		
536	351-49920-08	SCREW & WASHER AY	4		
537	002-37040-00	FLANGE NUT	4		
565	393-40651-08	HOUR METER	1	60HZ	
572	30G-45308-08	LAMP	1		
660	31H-75025-03	BREAKER	1		
661	352-45620-08	CIRCUIT PROTECTOR	1		
665	31B-79011-03	SCREW & WASHER AY	4		
666	351-49921-08	SCREW & WASHER AY	2		
671	363-45701-08	TERMINAL	1	RED 10A	
672	363-45700-08	TERMINAL	1	BLACK 10A	
680	356-49956-08	SCREW	1		
681	332-00050-08	SPRING WASHER	2		
682	353-49903-08	WASHER	1		
683	353-49902-08	NUT	1		
684	372-59950-08	LOCK WASHER	1		
685	353-49901-08	WING NUT	1		
720	31B-79012-03	BOLT AND WASHER AY	4		
767	31H-75028-03	CABLE CLIP	2		Electric Start Only
902	35H-71201-02	LABEL(MODEL)	1		

FIG. 26 GROUP




FIG. 26 GROUP

FIG. 27 GROUP




FIG. 27 GROUP

FIG. 29 GROUP




FIG. 29 GROUP

PRINTED IN THE USA

Robin America, Inc

905 Telser Road • Lake Zurich, IL 60047
Phone: 847-540-7300 • Fax: 847-438-5012
e-mail: sales@robinamerica.com • www.subarupower.com